


# Mobile Devices - Pairing Process

1. Power on your smart card reader

2. Make sure that Bluetooth is activated at your reader by pressing the AirID control element. AirID should display:



3. Make sure that Bluetooth is also activated on your mobile device (**Settings Bluetooth On**)

4. Open the third party app / AirID Central app and add your AirID. Your AirID should be listed with its serial number. Select the reader you want to connect with.

5. Follow the displayed instructions to pair the devices

After succesful pairing, "**Your device is ready to go!**" and the device name of the paired device will be displayed on your AirID.

If you already paired AirID with another device that are switched on and close to you, please navigate to "**Prefer Device**" in the AirID menu press the control element and choose "**New**". Then press the control element again to confirm.